

PHASEPERFECT[®]

230 V & 460 V

Digital Phase Converter

Operation & Installation Manual

Single-Phase to Three-Phase

Solid State Technology

95 - 98.7% Efficient



Product Manual

PHASEPERFECT[®] Digital Phase Converter



222 Disk Drive
Rapid City, SD 57701

Phone: 605-343-7934
Fax: 605-343-7943
Toll Free: 866-250-7934

www.phasetechnologies.com



2024 © Copyright, V4.3 All rights reserved. All contents are property of Phase Technologies, LLC.

No portion of this publication or its contents may be duplicated by any means, electronic or otherwise, without the express written consent of Phase Technologies, LLC.

V4.3_02232024

INTRODUCTION

The Phase Perfect® Digital Phase Converter converts single-phase AC power to three-phase AC power to operate a variety of electrical equipment. The Phase Perfect® delivers unmatched, three-phase voltage balance and operates at 98.7% efficiency.

Output voltage is sinusoidal with low harmonic content, making it safe to operate sensitive electronic equipment. The Phase Perfect® was designed to comply with IEEE 519 to meet utility regulatory standards.


Phase Perfect® Digital Phase Converters are available in NEMA 1 indoor enclosures and NEMA 3R outdoor enclosures with insect guards.





SAFETY MESSAGES AND WARNINGS

To ensure safe and reliable operation of the Phase Perfect®, it is important to carefully read this manual and to observe all warning labels attached to the unit before installing. Please follow all instructions exactly and keep this manual with the unit for quick and easy reference.


Definitions of Warning Signs and Symbols


 **CAUTION:** Indicates a potentially hazardous situation that could result in injury or damage to the product.


 **WARNING:** Indicates a potentially hazardous situation that could result in serious injury or death.


 **HIGH VOLTAGE:** The voltage associated with the procedures referenced could result in serious injury or death. Use caution and follow instructions carefully.


| |
|--|
| READ THESE WARNINGS BEFORE INSTALLING OR OPERATING EQUIPMENT! |
|--|


 **WARNING:** Risk of electric shock. More than one disconnect switch may be required to de-energize the equipment before servicing.

 **WARNING:** Risk of electric shock. De-energize the unit by disconnecting all incoming sources of power, then wait 30 minutes for internal charges to dissipate before servicing the equipment.

 **HIGH VOLTAGE:** This equipment is connected to line voltages that can create a potentially hazardous situation. Electric shock could result in serious injury or death. This device should be installed and serviced only by trained, licensed, and qualified personnel. Follow instructions carefully and observe all warnings.

 **WARNING:** Installation of this equipment must comply with the National Electrical Code (NEC) and all applicable local codes. Failure to observe and comply with these codes could result in risk of electric shock, fire, or damage to the equipment.

 **WARNING:** Grounding electrodes must be installed such that earth resistance is 25 Ohms or less, as specified by the NEC section 250-56. If surge protection is installed, earth resistance must be 3 Ohms or less for full effect. Failure to meet these requirements could result in serious injury or death and will void the manufacturer's warranty.

 **CAUTION:** Circuit breakers, fuses, proper ground circuits, and other safety equipment and their proper installation are not provided by Phase Technologies, LLC, and are the responsibility of the end user.



CAUTION: Failure to maintain adequate clearance may lead to overheating of the unit and cause damage or fire.



WARNING: Input power connections should be made by a qualified electrician into circuit with adequate voltage and current carrying capacity for the model. Branch circuit protection to the unit should be provided by appropriately sized fuses or a 2-pole circuit breaker.



CAUTION: Use 600 V vinyl-sheathed wire or equivalent. The voltage drop of the leads needs to be considered in determining wire size. Voltage drop is dependent on wire length and gauge. Use only copper conductors.



CAUTION: Wires fastened to the terminal blocks shall be secured by tightening the terminal screws to a torque value listed in **Table 18 - Table 22**.



CAUTION: The input wire gauge must be sized for the single-phase input current, which will be significantly larger than the three-phase output current to the load. The minimum wire gauge for the input terminals is listed in **Table 17**.



CAUTION: Never allow bare wire to contact metal surfaces.



CAUTION: Never connect AC main power to the output terminals T1, T2, and T3.



WARNING: Under certain conditions, the motor load may automatically restart after a trip has stopped it. Make sure power to the converter has been disconnected before approaching or servicing the equipment. Otherwise, serious injury may occur.

TABLE OF CONTENTS

| | |
|---|-----------|
| THEORY OF OPERATION | 1 |
| BLOCK DIAGRAM..... | 1 |
| MODELS AND RATINGS | 2 |
| SPECIFICATIONS | 3 |
| GENERAL SPECIFICATIONS | 3 |
| ELECTRICAL SPECIFICATIONS | 3 |
| MECHANICAL SPECIFICATIONS | 5 |
| INSTALLATION | 7 |
| MOUNTING YOUR NEW PHASE PERFECT | 7 |
| MOUNTING BRACKET INSTALLATION | 7 |
| NEMA 3R RAIN HOODS | 7 |
| PROPER VENTILATION | 7 |
| SERVICE ENTRANCE EQUIPMENT | 7 |
| SOURCE BRANCH CIRCUIT PROTECTION..... | 7 |
| GROUNDING | 8 |
| GENERATOR POWER..... | 10 |
| WIRE SIZING | 10 |
| CONNECTING THE LOAD | 10 |
| CONNECTING TO FIELD WIRING TERMINALS | 13 |
| ROUTING POWER CABLES | 15 |
| ON/OFF CONTROL WIRING | 17 |
| OPERATION..... | 19 |
| LCD STATUS SCREEN..... | 19 |
| DIP SWITCH SETTINGS | 19 |
| BYPASS AUX INPUTS..... | 20 |
| ENABLE VFD MODE..... | 20 |
| VOLTAGE CALIBRATION | 20 |
| TRANSFORMER MODE | 21 |
| ELEVATOR MODE..... | 22 |
| STARTUP DELAY | 23 |
| INFINITE RESTARTS..... | 24 |
| FAULT CODES | 25 |
| FAULTS: MANUAL RESTART | 26 |
| FAULT LOG..... | 26 |
| TROUBLESHOOTING TIPS | 27 |
| ROUTINE INSPECTION AND MAINTENANCE | 28 |
| LINE FILTER CAPACITORS..... | 28 |
| FUSES | 31 |
| MOTOR STARTING/OVERLOAD CAPABILITIES | 33 |
| DIMENSIONAL DRAWINGS..... | 37 |
| NOTES..... | 46 |
| WARRANTY POLICY | 47 |

THEORY OF OPERATION

L1 and L2 of the single-phase input pass directly through the phase converter to provide two legs of the three-phase output. The input module charges a DC bus from the input lines. The output module uses power from the DC bus to generate the third leg of the three-phase output. The third leg is generated to limit voltage imbalance between the three legs to $\leq 2\%$. Voltage imbalance is calculated according to the NEMA MG1 standard.

$$V_{ib} = \frac{V_{\max difference}}{V_{avg}}$$

Where:

$$V_{avg} = \frac{V_{T1T2} + V_{T2T3} + V_{T3T1}}{3}$$

$$V_{\max difference} = \text{MAX of } (|V_{T1T2} - V_{avg}|, |V_{T2T3} - V_{avg}|, |V_{T3T1} - V_{avg}|)$$

Block Diagram

The diagram in **Figure 1** illustrates the basic design schematic of the Phase Perfect Digital Phase Converter.




Figure 1 – Phase Perfect Digital Phase Converter Schematic

MODELS AND RATINGS




Figure 2 – Phase Perfect Nomenclature




Figure 3 – Phase Perfect Enterprise Nomenclature




Figure 4 – Phase Perfect Simple Nomenclature

SPECIFICATIONS

General Specifications

Table 1 – General Specifications

| | |
|--|--------------------------------|
| Output Voltage – Standard Models | Approx. equal to input voltage |
| Output Voltage – Voltage Doubling Models | Approx. 2 x input voltage |
| Output Voltage Imbalance | ≤2% |
| Operating Temperature – PT | -10°C (14°F) to 50°C (122°F) |
| Operating Temperature – PTE | -10°C (14°F) to 40°C (104°F) |
| Operating Temperature – PTS | -10°C (14°F) to 40°C (104°F) |
| Storage Temperature | -20°C (-4°F) to 60°C (140°F) |
| Efficiency – Standard Models | 98.7% |
| Efficiency – Voltage-Doubling Models | 95.0% |
| Short Circuit Withstand Rating | 10kA |
| Start Delay on Power Up | 2 sec |

Electrical Specifications

Table 2 – 230 V PT Models and Ratings

| Model | Power (HP) | Output (kVA) | Max Steady State Output Current (AAC) | Input Voltage Range (VAC) | Max AC Input Current (A) | Standby Power/Energy, (W/BTU/hr) | Full Load Energy Loss (BTU/hr) |
|-------|------------|--------------|---------------------------------------|---------------------------|--------------------------|----------------------------------|--------------------------------|
| PT007 | 7.5 | 10.8 | 26 | 187-260 | 45 | 70/239 | 479 |
| PT010 | 10 | 14.9 | 36 | | 62 | 74/252 | 661 |
| PT020 | 20 | 26.6 | 64 | | 111 | 80/273 | 1,180 |
| PT030 | 30 | 39.4 | 95 | | 165 | 175/597 | 1,752 |
| PT040 | 40 | 54.0 | 130 | | 225 | 190/648 | 2,395 |
| PT050 | 50 | 68.5 | 165 | | 286 | 235/802 | 3,043 |
| PT060 | 60 | 78.9 | 190 | | 329 | 260/887 | 3,500 |
| PT075 | 75 | 99.7 | 240 | | 416 | 300/1,024 | 4,427 |

Table 3 – 230 V PTE Models and Ratings

| Model | Power (HP) | Output (kVA) | Max Steady State Output Current (AAC) | Input Voltage Range (VAC) | Max AC Input Current (A) | Standby Power/Energy, (W/BTU/hr) | Full Load Energy Loss (BTU/hr) |
|--------|------------|--------------|---------------------------------------|---------------------------|--------------------------|----------------------------------|--------------------------------|
| PTE007 | 7.5 | 10.8 | 26 | 187-260 | 45 | 70/239 | 479 |
| PTE010 | 10 | 14.9 | 36 | | 62 | 74/252 | 661 |
| PTE015 | 15 | 21.6 | 52 | | 90 | 77/263 | 958 |
| PTE020 | 20 | 26.6 | 64 | | 111 | 80/273 | 1,180 |

Table 4 – 230 V PTS Models and Ratings

| Model | Power (HP) | Output (kVA) | Max Steady State Output Current (AAC) | Input Voltage Range (VAC) | Max AC Input Current (A) | Standby Power/Energy, (W/BTU/hr) | Full Load Energy Loss (BTU/hr) |
|--------|------------|--------------|---------------------------------------|---------------------------|--------------------------|----------------------------------|--------------------------------|
| PTS003 | 3 | 4.5 | 11 | 187-260 | 19 | 60/205 | 200 |
| PTS005 | 5 | 7.4 | 18 | | 31 | 60/205 | 328 |
| PTS007 | 7.5 | 10.8 | 26 | | 45 | 70/239 | 479 |

Table 5 – Voltage Doubling PTE Models and Ratings

| Model | Power (HP) | Output (kVA) | Max Steady State Output Current (AAC) | Input Voltage Range (VAC) | Max AC Input Current (A) | Standby Power/Energy (W/BTU/hr) | Full Load Energy Loss (BTU/hr) |
|----------|------------|--------------|---------------------------------------|---------------------------|--------------------------|---------------------------------|--------------------------------|
| PTE207QT | 7.5 | 10.8 | 13 | 187-260 | 45 | 200/682 | 1938 |
| PTE210QT | 10 | 14.9 | 18 | | 62 | 320/1,092 | 2685 |
| PTE215QT | 15 | 22.4 | 27 | | 94 | 435/1,484 | 4029 |
| PTE220QT | 20 | 26.6 | 32 | | 111 | 550/1,876 | 4777 |

Table 6 – 460 V PT Models and Ratings

| Model | Power (HP) | Output (kVA) | Max Steady State Output Current (AAC) | Input Voltage Range (VAC) | Max AC Input Current (A) | Standby Power/Energy, (W/BTU/hr) | Full Load Energy Loss (BTU/hr) |
|-------|------------|--------------|---------------------------------------|---------------------------|--------------------------|----------------------------------|--------------------------------|
| PT407 | 7.5 | 10.8 | 13 | 440-520 | 22 | 52/177 | 479 |
| PT410 | 10 | 14.9 | 18 | | 32 | 68/232 | 661 |
| PT415 | 15 | 22.4 | 27 | | 47 | 71/242 | 994 |
| PT420 | 20 | 26.6 | 32 | | 55 | 74/252 | 1,180 |
| PT430 | 30 | 38.2 | 46 | | 80 | 87/297 | 1,694 |
| PT440 | 40 | 50.7 | 61 | | 105 | 180/614 | 2,249 |

| | | | | | | | |
|---------------|-----|-------|-----|--|-----|-----------|-------|
| PT450 | 50 | 64 | 77 | | 134 | 190/648 | 2,839 |
| PT460 | 60 | 75.6 | 91 | | 157 | 220/751 | 3,358 |
| PT475 | 75 | 88.9 | 107 | | 185 | 270/921 | 3,992 |
| PT4100 | 100 | 118 | 142 | | 246 | 300/1,024 | 5,239 |
| PT4150 | 150 | 164.4 | 198 | | 343 | 330/1,126 | 7,305 |
| PT4175 | 175 | 183 | 220 | | 381 | 350/1,194 | 8,117 |

Table 7 – 460 V PTE Models and Ratings

| Model | Power (HP) | Output (kVA) | Max Steady State Output Current (AAC) | Input Voltage Range (VAC) | Max AC Input Current (A) | Standby Power/Energy, (W/BTU/hr) | Full Load Energy Loss (BTU/hr) |
|-----------------|------------|--------------|---------------------------------------|---------------------------|--------------------------|----------------------------------|--------------------------------|
| PTE407 | 7.5 | 10.8 | 13 | 440-520 | 22 | 52/177 | 479 |
| PTE410 | 10 | 14.9 | 18 | | 32 | 68/232 | 661 |
| PTE415QT | 15 | 22.4 | 27 | | 48 | 71/242 | 994 |
| PTE420QT | 20 | 26.6 | 32 | | 55 | 74/252 | 1,180 |

Table 8 – 460 V PTS Models and Ratings

| Model | Power (HP) | Output (kVA) | Max Steady State Output Current (AAC) | Input Voltage Range (VAC) | Max AC Input Current (A) | Standby Power/Energy, (W/BTU/hr) | Full Load Energy Loss (BTU/hr) |
|---------------|------------|--------------|---------------------------------------|---------------------------|--------------------------|----------------------------------|--------------------------------|
| PTS405 | 5 | 8.3 | 10 | 440-520 | 18 | 48/163 | 368 |
| PTS407 | 7.5 | 10.8 | 13 | | 22 | 52/177 | 479 |

Mechanical Specifications

Table 9 – 230 V PT Models – Enclosure Specifications

| Models | PT007 | PT010 | PT020 | PT030 | PT040 | PT050 | PT060 | PT075 |
|---|--------------------------------|-------|-------|-------------------------------|--------------------------------|---------------------------------|-------|-------|
| Dimensions Indoor: NEMA 1 (H x W x D)* | 36 15/16" x 25 3/8" x 17 1/16" | | | 32 13/16" x 20 3/4" x 14 3/4" | 36 1/4" x 27 13/16" x 15 3/4" | 44 15/16" x 25 13/16" x 16 3/4" | | |
| Dimensions Outdoor: NEMA 3R (H x W x D)* | 37 7/16" x 25 3/8" x 19 5/16" | | | 35 1/8" x 20 3/4" x 18 13/16" | 38 7/8" x 27 13/16" x 19 5/16" | 46 1/8" x 25 13/16" x 20 1/8" | | |
| Weight (lbs) | 102 | 104 | 129 | 222 | 233 | 251 | 255 | 288 |

Table 10 – 230 V PTE Models – Enclosure Specifications

| Models | PTE007 | PTE010 | PTE015 | PTE020 |
|-------------------------------|-----------------------------|-------------------------------|--------|--------|
| Indoor: NEMA 1 (HxWxD)* | 25 7/16" x 17 1/4" x 7 3/8" | 27 1/2" x 17 5/16" x 8 7/16" | | |
| Outdoor: NEMA 3R (H x W x D)* | 25 9/16" x 18 5/16" x 12" | 29 1/4" x 19 3/16" x 15 9/16" | | |
| Weight (lbs) | 51 | 51 | 71 | 72 |

Table 11 – 230 V PTS Models – Enclosure Specifications

| Models | PTS003 | PTS005 | PTS007 |
|-------------------------------|------------------------------|-------------------------------|--------|
| Indoor: NEMA 1 (H x W x D)* | 17 9/16" x 12 5/16" x 5 5/8" | 17 9/16" x 12 5/16" x 6 5/16" | |
| Outdoor: NEMA 3R (H x W x D)* | 17 7/8" x 13 1/4" x 10 1/2" | 18" x 13 1/4" x 11 1/4" | |
| Weight (lbs) | 20 | 22 | 24 |

Table 12 – Voltage Doubling PTE Models – Enclosure Specifications

| Models | PTE207 | PTE210 | PTE215 | PTE220 |
|-------------------------------|------------------------------|--------|--------|--------|
| Indoor: NEMA 1 (H x W x D)* | 33 9/16" x 18 9/16" x 8 3/8" | | | |
| Outdoor: NEMA 3R (H x W x D)* | 34 3/4" x 20" x 13 7/16" | | | |
| Weight (lbs) | 65 | 68 | 74 | 80 |

Table 13 – 460 V PT Models - Enclosure Specifications

| Models | PT407 | PT410 | PT415 | PT420 | PT430 | PT440 | PT450 | PT460 | PT475 | PT4100 | PT4150 | PT4175 |
|---------------------------|-------------------------------|-------|-------|-------|--------------------------------|---------------------------------|-------|-------|-------|--------|--------|--------|
| Indoor: NEMA 1 (HxWxD)* | 31 3/8" x 17 3/16" x 15 1/16" | | | | 36 15/16" x 25 3/8" x 17 1/16" | 44 15/16" x 25 13/16" x 16 3/4" | | | | | | |
| Outdoor: NEMA 3R (HxWxD)* | 31 3/8" x 22 7/16" x 15 1/16" | | | | 37 7/16" x 25 3/8" x 19 5/16" | 46 1/8" x 25 13/16" x 20 1/8" | | | | | | |
| Weight (lbs) | 70 | 74 | 80 | 80 | 141 | 242 | 246 | 256 | 268 | 305 | 305 | 305 |

Table 14 – 460 V PTE Models - Enclosure Specifications

| Models | PTE407 | PTE410 | PTE415 | PTE420 |
|-------------------------------|-------------------------------|--------|--------|--------|
| Indoor: NEMA 1 (H x W x D)* | 27 1/2" x 17 5/16" x 8 7/16" | | | |
| Outdoor: NEMA 3R (H x W x D)* | 29 1/4" x 19 3/16" x 15 9/16" | | | |
| Weight (lbs) | 69 | 70 | 70 | 72 |

Table 15 – 460 V PTS Models – Enclosure Specifications

| Models | PTS405 | PTS407 |
|-------------------------------|----------------------------|--------|
| Indoor: NEMA 1 (H x W x D)* | 18" x 14 1/8" x 6 5/16" | |
| Outdoor: NEMA 3R (H x W x D)* | 18 11/16" x 15" x 11 3/16" | |
| Weight (lbs) | 25 | 25 |

*Note: Dimensions are maximum measurements including mounting hardware and optional MCCB handle, where applicable. Weights include MCCB.

INSTALLATION

Mounting Your New Phase Perfect

Proper installation of the unit is important to the performance and normal operating life of the unit. The unit should be installed in a location free from:

- Corrosive gases or liquids
- Excessive vibration
- Airborne metallic particles

Mount the unit to a solid, non-flammable surface capable of bearing the weight using the mounting brackets provided with the unit. Model weights are found in **Table 9 – Table 14**.

Mounting Bracket Installation

For shipping purposes, mounting brackets may be installed upside down, or shipped separately in a bag. If the mounting brackets are not installed in an upright position, remove the mounting screws, turn to an upright position, and then fasten the screws tightly.

NEMA 3R Rain Hoods

Phase Perfect phase converters can be ordered in NEMA 1 indoor or NEMA 3R outdoor rated enclosures. Exterior openings on the top and sides of enclosure must be covered by a rain hood to be NEMA 3R outdoor rated. If the unit is being installed outdoors, install the supplied rain hood before operation. Installing products outdoors without the proper rain hood will void the manufacturer warranty.

Proper Ventilation

To maintain air circulation for adequate cooling, minimum clearance around the unit must be maintained. Allow six inches on each side and top, and at least 18 inches below.

Ensure air intake and exhaust openings are not obstructed. If the unit is mounted in a small room, cabinet, or building, ensure there is adequate ventilation to provide sufficient cooling.

Service Entrance Equipment

Phase Perfect phase converters are suitable for use as service equipment when the molded case circuit breaker (MCCB)/disconnect, service ground conductor terminal, and grounding electrode conductor are factory installed and the converter is labeled "Suitable for use as Service Equipment." Consult local electrical code for installation guidance.

Source Branch Circuit Protection

If a circuit breaker is not factory installed, branch circuit protection must be installed in the circuit sourcing the phase converter. See **Table 16** for recommended circuit breaker sizing. Fuses may be used for circuit protection, consult local electrical code for proper sizing. Installation of a disconnection means within sight of the phase converter is recommended.

Grounding

- Properly ground the phase converter according to local electrical code.
- Connect the ground lug to the branch circuit or service ground conductor.
- Ground the phase converter with an adequately sized conductor according to local electrical code.
- Ground wire recommendations based on solid to semi-rigid stranded copper wire.

Table 16 – Ground Wire Specifications

| Models | Recommended Circuit Breaker (A) | Wire Range (AWG) | |
|---------------------|------------------------------------|------------------|-----|
| | | Min | Max |
| PTS003 | 30 | 10 | 2 |
| PTS005 | 40 | 10 | 2 |
| PT007/PTE007/PTS007 | 60 | 10 | 2 |
| PT010/PTE010 | 80 | 8 | 2 |
| PTE015 | 125 | 6 | 2 |
| PT020/PTE020 | 150 | 6 | 2 |
| PT030 | 225 | 4 | 2 |
| PT040 | 300 | 4 | 2 |
| PT050 | 400 | 3 | 2/0 |
| PT060 | 500 | 2 | 2/0 |
| PT075 | 600 | 1 | 2/0 |
| PTE207 | 60 | 8 | 2 |
| PTE210 | 80 | 6 | 2 |
| PTE215 | 125 | 6 | 2 |
| PTE220 | 150 | 6 | 2 |
| PTS405 | 30 | 10 | 2 |
| PT407/PTE407/PTS407 | 30 | 10 | 2 |
| PT410/PTE410 | 40 | 10 | 2 |
| PT415/PTE415 | 60 | 10 | 2 |
| PT420/PTE420 | 70 | 8 | 2 |
| PT430 | 100 | 8 | 2 |
| PT440 | 150 | 6 | 2 |
| PT450 | 175 | 6 | 2 |
| PT460 | 200 | 6 | 2 |
| PT475 | 250 | 4 | 2 |
| PT4100 | 400 | 3 | 2/0 |
| PT4150 | 400 | 3 | 2/0 |
| PT4175 | 500 | 3 | 2/0 |

See terminal markings for additional wire size and torque information.

Connecting Source Power

Table 17 – Input Wiring

Wire size recommendations based on 600 VAC copper wire, rated either 60°C or 75°C. Assuming 104°F (40°C) ambient and no more than 3 current carrying conductors in raceway or earth (directly buried). If phase converter will be in warmer environments, consult NEC Handbook for temperature correction factor.

| Input Wiring Recommendations | | |
|------------------------------|------------------------|------------------------|
| | Min. Wire Gauge (60°C) | Min. Wire Gauge (75°C) |
| PTS003 | 10 AWG | 14 AWG |
| PTS005 | 8 AWG | 10 AWG |
| PT007/PTE007/PTS007 | 4 AWG | 6 AWG |
| PT010/PTE010 | 3 AWG | 4 AWG |
| PTE015 | 1/0 AWG | 1 AWG |
| PT020/PTE020 | - | 1/0 AWG |
| PT030 | 300 kcmil | 4/0 AWG |
| PT040 | - | 350 kcmil |
| PT050 | 2 x 250 kcmil | 2 x 3/0 AWG |
| PT060 | 2 x 300 kcmil | 2 x 250 kcmil |
| PT075 | 2 x 500 kcmil | 2 x 350 kcmil |
| | | |
| PTE207 | 4 AWG | 6 AWG |
| PTE210 | 3 AWG | 4 AWG |
| PTE215 | 1/0 AWG | 1 AWG |
| PTE220 | - | 1/0 AWG |
| | | |
| PTS405 | 10 AWG | 14 AWG |
| PT407/PTE407/PTS407 | 10 AWG | 10 AWG |
| PT410/PTE410 | 8 AWG | 8 AWG |
| PT415/PTE415 | 4 AWG | 6 AWG |
| PT420/PTE420 | 4 AWG | 4 AWG |
| PT430 | 1 AWG | 3 AWG |
| PT440 | - | 1/0 AWG |
| PT450 | - | 2/0 AWG |
| PT460 | 250 kcmil | 3/0 AWG |
| PT475 | 350 kcmil | 250 kcmil |
| PT4100 | 2 x 250 kcmil | 2 x 3/0 AWG |
| PT4150 | 2 x 250 kcmil | 2 x 3/0 AWG |
| PT4175 | 2 x 250 kcmil | 2 x 3/0 AWG |

Generator Power

Phase Perfect phase converters can be powered by a generator, but it is recommended that generator be sized 150% of the phase converter rating for proper operation. If a generator will be used for backup power, a delay timer must be used to allow the phase converter to completely shut down before transferring to a new power source. This delay should be a minimum of 15 seconds.

Wire Sizing

Use **Table 17** to find minimum guidelines on properly sizing input conductors according to local electrical code. The voltage drop from the supply to the converter should be limited to 3% to ensure proper starting and operation of motor loads. Increase the wire gauge to provide adequate voltage to the load. Ensure the wire gauge is suitable to the terminal block.

Use the following formula to calculate line voltage drop.

$$V_{drop} = \text{wire resistance} \left(\frac{\Omega}{ft} \right) \times \text{wire length (ft)} \times \text{current}$$

Connecting the Load

Do not connect single-phase loads to the manufactured leg, T3. This places unnecessary load on the phase converter and may violate electrical code in some areas. Apply overload and short circuit protection to protect load side conductors, motors, and other attached loads according to local electrical code. For some motor loads and wiring configurations load side short circuit protection may not be required. Consult local electrical code for guidance.

Important Note:

If the connected load requires a wye configured power source with a neutral connection, the load must be connected to the phase converter using a delta-wye isolation transformer.




Figure 5 – Delta-Wye Wiring Diagram

Table 18 – Input Power Terminal Specifications - PT

| Input Power Terminals: Allowed Wire Range & Minimum Torque | | | | | |
|---|-----------|-------------------------------|-----------|--|-----------|
| Model | | | | | |
| PT007, PT010, PT020, PT407, PT410, PT415, PT420, PT430, PT440, PT450 | | PT030, PT040, PT460, PT475 | | PT050, PT060, PT075, PT4100, PT4150, PT4175 | |
| Wire Size | Torque | Wire Size | Torque | Wire Size | Torque |
| 2/0 – 6 AWG | 120 in-lb | 350 kcmil- 6 AWG | 275 in-lb | 2x500 kcmil- 2x4 AWG | 375 in-lb |
| 8 AWG | 40 in-lb | | | | |
| 10 – 14 AWG | 35 in-lb | | | | |

Table 19 – Input Power Terminal Specifications - PTE

| Input Power Terminals: Allowed Wire Range & Minimum Torque | | | |
|--|------------|-------------------------------------|-----------------------------------|
| Model | | | |
| PTE007, PTE007QT, PTE010, PTE010QT, PTE207QT, PTE210QT, PTE215QT, PTE220QT, PTE407, PTE410, PTE415QT, PTE420QT | | PTE015, PTE020 | |
| Wire Size | Torque | Wire Size | Torque |
| 2/0 – 16 AWG | 17.5 in-lb | 2/0 – 6 AWG 8 AWG 10 – 14 AWG | 120 in-lb 40 in-lb 35 in-lb |

Table 20 – Input Power Terminal Specifications - PTS

| Input Power Terminals: Allowed Wire Range & Minimum Torque | |
|--|------------|
| Model | |
| PTS003, PTS005, PTS007, PTS405, PTS407 | |
| Wire Size | Torque |
| 6 – 26 AWG | 10.5 in-lb |

Table 21 – Output Power Terminal Specifications

| Output Power Terminals: Allowed Wire Range & Minimum Torque | | | |
|--|-----------|--|-----------|
| Model | | | |
| PT007, PT010, PT020, PT030, PT040, PT407, PT410, PT415, PT420, PT430, PT440, PT450, PT460, PT475 | | PT050, PT060, PT075, PT4100, PT4150, PT4175 | |
| Wire Size | Torque | Wire Size | Torque |
| 2/0 – 6 AWG | 120 in-lb | 350 kcmil – 6 AWG | 275 in-lb |
| 8 AWG | 40 in-lb | | |
| 10 – 14 AWG | 35 in-lb | | |

Table 22 – Output Power Terminal Specifications - PTE

| Output Power Terminals: Allowed Wire Range & Minimum Torque | |
|---|-----------|
| Model | |
| PTE007, PTE007QT, PTE010, PTE010QT, PTE015, PTE020, PTE207QT, PTE210QT, PTE215QT, PTE220QT, PTE407, PTE407QT PTE410, PTE415QT, PTE420QT | |
| Wire Size | Torque |
| 4 – 18 AWG | 16 in-lbs |

Table 23 – Output Power Terminal Specifications – PTS

| Output Power Terminals: Allowed Wire Range & Minimum Torque | | | |
|---|-------------|----------------|-----------|
| Model | | | |
| PTS003, PTS005, PTS007 | | PTS405, PTS407 | |
| Wire Size | Torque | Wire Size | Torque |
| 6 – 26 AWG | 10.5 in-lbs | 8 – 16 AWG | 20 in-lbs |

Table 24 – Field Wiring Tools

| Model | Line Side | Load Side |
|-------|-----------|-----------|
| PT007 | 3/16" Hex | 3/16" Hex |
| PT010 | | |
| PT020 | | |
| PT030 | | |
| PT040 | 5/16" Hex | 5/16" Hex |
| PT050 | | |
| PT060 | | |
| PT075 | | |

| Model | Line Side | Load Side |
|--------|-----------|-----------|
| PT407 | 3/16" Hex | 3/16" Hex |
| PT410 | | |
| PT415 | | |
| PT420 | | |
| PT430 | | |
| PT440 | | |
| PT450 | 5/16" Hex | 3/16" Hex |
| PT460 | | |
| PT475 | | |
| PT4100 | | |
| PT4150 | | |
| PT4175 | | |

| Model | Line Side | Load Side |
|----------|-------------------------|-------------------------|
| PTE007 | Phillips Screwdriver | Flathead Screwdriver |
| PTE007QT | | |
| PTE010 | | |
| PTE010QT | | |
| PTE015 | 3/16" Hex | |
| PTE020 | | |
| PTE207QT | Phillips Screwdriver | |
| PTE210QT | 3/16" Hex | |
| PTE215QT | | |
| PTE220QT | | |

| Model | Line Side | Load Side |
|----------|----------------------|----------------------|
| PTE407 | Phillips Screwdriver | Flathead Screwdriver |
| PTE407QT | | |
| PTE410 | | |
| PTE410QT | | |
| PTE415QT | | |
| PTE420QT | | |

| Model | Line Side | Load Side |
|--------|----------------------|----------------------|
| PTS003 | Flathead Screwdriver | Flathead Screwdriver |
| PTS005 | | |
| PTS007 | | Phillips Screwdriver |
| PTS405 | | |
| PTS407 | | |

Table 25 – Optional Circuit Breaker Wire Size and Torque

| Models | Circuit Breaker Family | Min | Max | Min Torque (in-lb) | Wire Strip |
|---|------------------------|-----------|-----------|--------------------|------------|
| PT007 PT010 PT407 PT410 PT415 PT420 PT430 | LS UTE100 | 14 | 10 | 31.9 | 0.7" |
| | | 8 | | 39.9 | |
| | | 6 | 3 | 47.8 | |
| | | 2 | 1 | 55.7 | |
| PT020 PT440 | LS UTS150 | 14 | | 36.2 | 1.01" |
| | | 12 | 10 | 47.8 | |
| | | 8 | 2/0 | 133.6 | |
| PT030 PT450 PT460 PT475 | LS UTS250 | 1/0 | 2/0 | 254.9 | 1.27" |
| | | 3/0 | 4/0 | 350.5 | |
| | | 250 kcmil | 300 kcmil | 350.5 | |
| PT040 PT050 PT4100 PT4150 PT4175 | LS UTS400 | 1/0 | 300 kcmil | 358.4 | 1.76" |
| | | 350 kcmil | 600 kcmil | 477.9 | |
| | | | | | |

Connecting to Field Wiring Terminals

Open the front door of the enclosure to gain access to the wiring panel. See **Figure 6 - Figure 10**.




Figure 6 – PT Small Frame Field Wiring Terminals




Figure 7 – PT Medium Frame Field Wiring Terminals

Small Frame Models:
PT407, PT410, PT415,
PT420

Medium Frame Models:
PT007, PT010, PT020,
PT430

Large Frame Models:
PT030, PT040, PT050,
PT060, PT075, PT440,
PT450, PT460, PT475,
PT4100, PT4150, PT4175




Figure 8 – PT Large Frame Field Wiring Terminals

Table 26 – Power Terminal Descriptions

| Terminal Name | Description |
|---------------|---|
| L1, L2 | Single phase input power terminals |
| T1, T2, T3 | 3 Phase output power terminals, T3 is the “manufactured” leg. |
| GND | Earth ground |




Figure 9 – PTE Field Wiring Terminals: PTE007, PTE007QT, PTE010, PTE010QT, PTE207, PTE407, PTE407QT, PTE410, PTE415QT, PTE420QT




Figure 10 – PTE Field Wiring Terminals: PTE015, PTE020, PTE210, PTE215, PTE220




Figure 11 – PTS Field Wiring Terminals:
PTS003, PTS005, PTS007




Figure 12 – PTS Field Wiring Terminals:
PTS405, PTS407

Routing Power Cables

Note: Continuous metal conduit should be used for all power cables to reduce radiated electromagnetic interference (EMI). The conduit must be securely grounded to the converter enclosure and the motor case. Conduit hubs should be IMC or rigid steel conduit and be UL listed. Conduit hub locations can be seen in **Figure 13 - Figure 17**.

Route power cables through the supplied openings in the bottom of the enclosure, using appropriate conduit or strain relief devices. If any conduit holes remain unused, they must be covered with a 3R hole plug to maintain the NEMA 3R rating.

Important Note: If new openings are cut, be sure to completely remove all resulting metal shavings.




Figure 13 – PT Small Frame Conduit Locations




Figure 14 – PT Medium Frame Conduit Locations

Small Frame Models:
PT407, PT410, PT415,
PT420

Medium Frame Models:
PT007, PT010, PT020,
PT430

Large Frame Models:
PT030, PT040, PT050,
PT060, PT075, PT440,
PT450, PT460, PT475,
PT4100, PT4150, PT4175




Figure 15 – PT Large Frame Conduit Locations




Figure 16 – PTE Conduit Locations:
PTE007, PTE007QT, PTE010, PTE010QT,
PTE407, PTE407QT, PTE410, PTE415QT,
PTE420QT




Figure 17 – PTE Conduit Locations:
PTE015, PTE020, PTE207QT, PTE210QT,
PTE215QT, PTE220QT




Figure 18 – PTS Conduit Locations – All Models

On/Off Control Wiring

The output of the converter can be controlled with a switch connected between the AUX1 or AUX2 and COM terminals. If installed, remove the factory installed jumper wire and replace with a switch. Jumper wire can be seen in **Figure 19** below.




Figure 19 – Control Terminal Locations

When AUX1 to COM or AUX2 to COM is closed, the output is energized after a delay of approximately two seconds. When AUX1 and AUX2 to COM are open, the output of the converter will be de-energized. The diagram in **Figure 20** illustrates the UL508A panel shop and customer installed options including an ON/OFF control switch. Unused conduit holes must be filled with a conduit hole plug.




Figure 20 – Panel Shop Options



WARNING! When the converter is turned OFF using a switch on the AUX terminals, dangerous voltage may still be present on the input lines and elsewhere inside the enclosure. **Never open the enclosure or perform maintenance on the unit or connected loads when the incoming power to the phase converter is ON, regardless of the switch setting.**

Table 27 – Control Terminal Ratings and Descriptions

| Terminal | Description | Rating | Comments |
|----------|-------------------|--|---|
| AUX1 | Auxiliary Input 1 | Dry contact type Pullup Voltage < 5 volts, galvanically isolated | Digital input. Commonly used for ON/OFF control of output. |
| AUX2 | Auxiliary Input 2 | | Common for AUX terminals. |
| COM | Common | | |
| AUX3 | Auxiliary Input 3 | | Used for programming different modes. See next section for details. |
| AUX4 | Auxiliary Input 4 | | |



CAUTION! Electrostatic discharge (ESD) can damage electronic components. Discharge ESD prior to touching the board or making connections. To discharge ESD, touch your hand to unpainted metal on the enclosure.

OPERATION

LCD Status Screen

When the unit is powered up, the screen will scroll through the operating parameters.



Figure 21 – Status Screen



Figure 22 – “System Off” Status Screen

DIP Switch Settings

⚠ WARNING! Make sure the input power disconnect switch is in the OFF position before opening the front cover to the unit. Opening the front cover with the switch in the ON position exposes the user to the risk of electric shock.

⚠ WARNING: Risk of electric shock. Disconnect all incoming sources of power and wait 30 minutes before opening the front cover to change the DIP switch.




Figure 23 – Location of DIP Switches and Slide Switches

Table 28 – DIP Switch Settings

| DIP Switch | Function | Default |
|------------|---------------------------------------|---------|
| 9 & 10 | Bypass AUX1 & AUX2 both ON | OFF/OFF |
| 10 | Enable VFD Mode note: SW9 must be OFF | OFF |


Bypass AUX Inputs

When both DIP switches 9 and 10 are in the **ON** position, AUX1 and AUX2 inputs will be bypassed causing the output to energize regardless of the state of AUX1 and AUX2.

Enable VFD Mode

In VFD mode the phase converter will automatically adjust the current on the generated leg to balance the three-phase currents by adjusting the voltage of the generated leg. In this mode, the output voltage may not be balanced. This function is typically used to prevent overheating of the VFD due to unbalanced currents induced by the non-linear nature of the VFD inverter. Turn power to the unit off and set DIP switch 10 to the **ON** position to enable VFD mode.

Voltage Calibration

 **WARNING!** Risk of electric shock. De-energize the unit by disconnecting all incoming sources of power, then wait 30 minutes for internal charges to dissipate before servicing the equipment.

Calibrating voltage will require wiring two ON/OFF switches to the converter. Standard light switches will work. See **Figure 24** below, for wiring diagram.




Figure 24 – Wiring Diagram for SW3 and SW4

To adjust output voltage, follow the steps below:


| Step | Action |
|------|---|
| 1 | Turn power to PT OFF |
| 2 | Remove jumper wire between AUX1 and COM |
| 3 | Wire dry contact switch between AUX3 and COM (now called SW3) |
| 4 | Wire dry contact switch between AUX4 and COM (now called SW4) |
| 5 | Turn power to the PT ON |
| 6 | SW4: ON |
| 7 | SW3: ON |

Toggle SW4 to move between **ADJUST V23** and **ADJUST V31**. When the desired parameter is shown on the display, toggle SW3 **OFF** then **ON** to enter the selected menu.

| Action | Effect |
|-------------------|---------------------------|
| Toggle SW3 | Decrease selected voltage |
| Toggle SW4 | Increase selected voltage |

When adjusting output voltage, make changes in small increments (5 V or less) to begin, then let the menu time out to save the change. After **"Programmed Successfully"** is shown on the display, return switches to the **OFF** position. Turn power to converter **OFF**, re-install jumper wire between **AUX1** and **COM**, then reapply power to converter and measure voltages to verify change in calibration. Repeat this procedure, using smaller increments as you get close, until desired output voltage is reached. When voltage calibration has been completed, turn power to the PT **OFF**. Remove SW3 and SW4, re-install the jumper wire connecting AUX1 and COM and re-apply power to converter.

Transformer Mode

 **WARNING!** Risk of electric shock. De-energize the unit by disconnecting all incoming sources of power, then wait 30 minutes for internal charges to dissipate before servicing the equipment.

Transformer Mode will allow T3 to drop in voltage during heavy startups. This will require wiring two ON/OFF switches to the converter. Standard light switches will work. See **Figure 24**, for wiring diagram.

To enable **Transformer Mode**, follow the steps below:

| Step | Action |
|------|---|
| 1 | Turn power to PT OFF |
| 2 | Remove jumper wire between AUX1 and COM |
| 3 | Wire dry contact switch between AUX3 and COM (now called SW3) |
| 4 | Wire dry contact switch between AUX4 and COM (now called SW4) |
| 5 | Turn power to the PT ON |
| 6 | Toggle SW4 until you see TRANSFORMER 2/5 on display |
| 7 | Toggle SW3 to select between YES or NO |

Leave Transformer select menu at desired setting, after 3 seconds of no switch toggling, the setting will be saved. **Switches must be returned to the OFF position after changes are complete.** Turn power to the PT **OFF** again. Remove SW3 and SW4, re-install the jumper wire connecting AUX1 and COM, and re-apply power to converter.

Elevator Mode



WARNING! Risk of electric shock. De-energize the unit by disconnecting all incoming sources of power, then wait 30 minutes for internal charges to dissipate before servicing the equipment.



WARNING! Using **Elevator Mode** on any application except an elevator will void manufacturer's warranty. **Transformer Mode** and **VFD Mode** can be used on any application without voiding warranty.

Elevator Mode forces T3 to maintain voltage during heavy startups. This setting should only be used if elevator is tripping due to a drop in input voltage. This will require wiring two ON/OFF switches to the converter. Standard light switches will work. See **Figure 24** for wiring diagram. To enable **Elevator Mode**, follow the steps below:

| Step | Action |
|------|---|
| 1 | Turn power to PT OFF |
| 2 | Remove jumper wire between AUX1 and COM |
| 3 | Wire dry contact switch between AUX3 and COM (now called SW3) |
| 4 | Wire dry contact switch between AUX4 and COM (now called SW4) |
| 5 | Turn power to the PT ON |
| 6 | Toggle SW4 until you see ELEVATOR on screen |
| 7 | Toggle SW3 to select between YES or NO |

Leave Elevator select menu at desired setting, after 3 seconds of no switch toggling, the setting will be saved. **Switches must be returned to the OFF position after changes are complete.** Turn power to the PT **OFF** again. Remove SW3 and SW4, re-install the jumper wire connecting AUX1 and COM and re-apply power to converter.

Startup Delay



WARNING! Risk of electric shock. De-energize the unit by disconnecting all incoming sources of power, then wait 30 minutes for internal charges to dissipate before servicing the equipment.

Startup Delay will force the converter to wait for a set time period before starting up. This procedure will require wiring two ON/OFF switches to the converter. Standard light switches will work. See **Figure 24** for wiring diagram. To add a startup delay, follow the steps below:

| Step | Action |
|------|--|
| 1 | Turn power to PT OFF |
| 2 | Remove jumper wire between AUX1 and COM |
| 3 | Wire dry contact switch between AUX3 and COM (now called SW3) |
| 4 | Wire dry contact switch between AUX4 and COM (now called SW4) |
| 5 | Turn power to the PT ON |
| 6 | Toggle SW4 until you see STARTUP DLY 4/5 on screen |
| 7 | Toggle SW3 to select between YES or NO |
| 8 | Wait several seconds to allow this programming to be saved |
| 9 | Repeat steps 6 and 7 |
| 10 | SW3 ON to access STARTUP DLY |
| 11 | SW4 ON to access DLY TIME |

Switches now act as toggle to select the **STARTUP DELAY TIME**.

| Action | Effect |
|-------------------|---------------------|
| Toggle SW3 | Decrease delay time |
| Toggle SW4 | Increase delay time |

Wait several seconds until **"Programmed Successfully"** is shown on the display, and then return switches to the **OFF** position. Turn power to converter **OFF**, re-install jumper wire between **AUX1** and **COM**, then reapply power to converter.

Infinite Restarts



WARNING! Risk of electric shock. De-energize the unit by disconnecting all incoming sources of power, then wait 30 minutes for internal charges to dissipate before servicing the equipment.

Infinite Restarts will allow the converter to restart an unlimited number of times after fault conditions. This procedure will require wiring two ON/OFF switches to the converter. Standard light switches will work. See **Figure 24** for wiring diagram. To add a startup delay, follow the steps below:

| Step | Action |
|------|---|
| 1 | Turn power to PT OFF |
| 2 | Remove jumper wire between AUX1 and COM |
| 3 | Wire dry contact switch between AUX3 and COM (now called SW3) |
| 4 | Wire dry contact switch between AUX4 and COM (now called SW4) |
| 5 | Turn power to the PT ON |
| 6 | Toggle SW4 until you see INFINITE RESTARTS on screen |
| 7 | Toggle SW3 to select between YES or NO |

Wait several seconds until "**Programmed Successfully**" is shown on the display, and then return switches to the **OFF** position. Turn power to converter **OFF**, re-install jumper wire between **AUX1** and **COM**, then reapply power to converter.

Fault Codes

Table 29 – Fault Codes

| Text | Description/Comments | Restart |
|-------------------|--|---------|
| BUS OVERVOLTAGE | Sudden and severe regenerative power under high line voltage may result in bus overvoltage. | Auto |
| CLASS 4 OVERLOAD | Output current exceeded operating limit. | Auto |
| CM BOARD FAULT | Connection from Control board to Hall Sensor isn't properly connected. Power down unit, reconnect, and restart. | Auto |
| HALL SENSE HIGH | Current exceeded the maximum rating of the Hall sensor. May indicate a fault in the motor circuit. | Auto |
| HIGH INPUT VOLT | Input voltage has exceeded a safe operating level. Reduce input voltage. | Auto |
| IGBT FAULT | Check for short circuit on input and output lines and load. Contact Phase Technologies. | Auto |
| LOW INPUT VOLT | Input voltage has fallen below a safe operating level. | Auto |
| OUTPUT OVERLOAD | A large and sudden overcurrent event on the output module. Check motor circuit for faults. | Auto |
| OVER TEMPERATURE | Internal temperature of the converter exceeded safe operating limits. Check fans and ventilation openings for obstruction. Reduce ambient temperature. | Auto |
| OVERCURRENT INPUT | Input current exceeded the operating limit. | Auto |
| PLL FAULT | Phase-Locked Loop occurs when input frequency is ± 7 Hz of 60 Hz. Check input frequency. | Auto |
| PRECHARGE FAIL | Pre-charge circuit has failed to charge bus capacitors. | Manual |
| STIR FAN FAIL | PT420 and PTE420QT only. Temperature sensor near inductor has exceed safe operating limits. Wait for temperature to drop to safe level. | Auto |
| TEMP SENSE FAULT | Temperature sensor on the heat sink has failed or its cable is disconnected. | Manual* |
| UNBALANCE BUS VOL | Potential damage to a bus capacitor or degradation of the bus balancing resistor. | Auto |
| VOLTAGE UNBALANCE | Output voltage difference between pass-through legs and generated leg is greater than 50 V. | Manual* |

* - Faults will automatically restart if Infinite Restart mode is enabled.

Faults: Manual Restart

These faults generally indicate damage to the converter and/or the load. They may also indicate a potentially dangerous condition. When this type of fault occurs, the display will indicate the fault message and the converter output will remain off.



CAUTION! Contact Phase Technologies for assistance before restarting or troubleshoot the system thoroughly before power cycling the converter.



WARNING! Risk of electric shock. De-energize the unit by disconnecting all incoming sources of power, then wait 30 minutes for internal charges to dissipate before servicing the equipment.

Fault Log

The Fault Log records faults with number of occurrences. To access the Fault Log, wire a dry contact switch between AUX3 and COM (now called SW3), and wire a dry contact switch between AUX4 and COM (now called SW4). Standard light switches will work. Next, set SW3 and SW4 per **Table 30**. There are two fault logs – Master and User Fault Log.

Master Fault Log:

A non-resettable count of all faults over the life of the main circuit board

User Fault Log:

A resettable count of faults. Each fault type is limited to a count of 10. On the 11th fault, the unit will display the appropriate fault and the LCD screen will display “RESET? PWR CYCLE”.

Power cycling the unit will reset the fault back to zero.

Table 30 – Modes for SW3 and SW4 (ON = up, OFF = down)

| SW3 | SW4 | Result |
|-----|-----|--|
| OFF | OFF | Factory default: LCD screen will scroll various operating parameters – UNIT WILL OPERATE WHILE IN THIS MODE |
| ON | OFF | LCD screen will show Master Fault Log (non-resettable count of all faults) UNIT WILL NOT OPERATE WHILE IN THIS MODE |
| ON | ON | LCD screen will show User Fault Log (resettable count of all faults) UNIT WILL NOT OPERATE WHILE IN THIS MODE |
| OFF | ON | Reserved |

TROUBLESHOOTING TIPS

If a fault occurs, a fault code will be displayed on the LCD screen. See **Table 29** for a list of fault codes. Fault codes generally indicate that an issue exists independent of the phase converter.

Table 31 – Troubleshooting

| Problem | Potential Cause | Solution |
|--|--|--|
| No power | Incoming circuit breaker continually trips | IGBT troubleshooting |
| | Blown fuses | See page 31 for information on replacing fuses. If fuses are blown, this may also require replacing filter capacitors and/or the power board if the MOV's are damaged. |
| Load not operating | Fault code displayed | Use Table 29 for more information and guidance on fault codes. Clear the fault by power cycling the converter. Remove the load to determine if the issue is internal or external to the unit. |
| | AUX1 and AUX2 open | Check the jumper or switches connected to the AUX1 and/or AUX2 inputs |
| | Signals to the Control Terminals corrupted | Shielded cable is required for AUX terminal leads longer than 20 ft. |
| | Input terminals L1 and L2 not energized | Check the main input fuses or breaker. Check the secondary circuit fuses. See Figure 32 - Figure 34 . |
| | Overcurrent fault in elevator application | Check elevator specs to ensure PT is sized correctly. |
| Motor is spinning backwards | Phase sequence to motor is wrong. | Swap any two of the three motor leads. |
| LED lights flickering or other electrical noise issues | Electromagnetic interference issues | Ensure that problem does not persist when PT is powered off. Check and improve grounding. LED lighting can be prone to noise/flickering when all LED lights are being used. Installing an incandescent light in a given circuit can often resolve these problems. Consider installing an EMI filter on the phase converter input. |

ROUTINE INSPECTION AND MAINTENANCE



HIGH VOLTAGE: This equipment is connected to line voltages that can create a potentially hazardous situation. Electric shock could result in serious injury or death. This device should only be installed and serviced by trained and licensed personnel. Follow instructions carefully and observe all warnings.



WARNING! Under certain operating conditions, the converter will shut down and automatically restart. Always disconnect input power from the unit and wait 30 minutes for charge to dissipate before performing service on the converter or connected loads.

Overall: Perform visual inspection, checking for things such as discolored wires or terminals, evidence of arcing, loose mounting screws, physical damage to the enclosure, etc. The converter should be inspected and cleaned annually or more frequently if located in a hot or dirty environment. Special attention should be given to the following:

Power terminals: Periodically, inspect for loose connections and tighten to specifications in **Table 18 – Table 22**.

Capacitors: Check for leakage or deformation.

Fans and heatsinks: Excessive dust buildup on heatsink or fan impellers may lead to overheating. Lightly brush and vacuum. Contact Customer Service for assistance in replacing cooling fans. Use only fans approved by Phase Technologies. Unapproved fans may lead to component damage.

Line Filter Capacitors

This section does not apply to PTS products. Line filter capacitors are part of the inductor/capacitor (L/C) filters and should be routinely monitored and replaced if degraded. Failure of the L/C filter can lead to increased harmonic levels, which may damage equipment connected to converter. See **Figure 25 - Figure 27** to identify the line filter capacitors.




Figure 25 – PT Small Frame Line Filter Capacitors




Figure 26 – PT Medium Frame Line Filter Capacitors




Figure 27 – PT Large Frame Line Filter Capacitors




Figure 28 – PTE Frame 1 Line Filter Capacitors

Figure 29 – PTE Frame 2 Line Filter Capacitors

Visually inspect the line filter capacitors and connecting wires for any discoloration or bulges in the canisters.

For **PT Small Frames**, disconnect the wires from the capacitor being measured, noting where they were connected. Use a multi-meter to measure capacitance between the terminals of one capacitor at a time. If the capacitance of either is below the **50% Capacitance** value in **Table 32**, contact Phase Technologies for replacement.

For **PT Medium** and **Large Frames**, disconnect wires from L2 and use a multi-meter to measure between L1 and L2, then measure between L2 and L3. If either capacitance measured is below the **50% Capacitance** value in **Table 32**, contact Phase Technologies for replacement.

Table 32 – PT Nominal Filter Capacitor Values in MicroFarads (uF)

| Converter Model | Nominal Capacitance | 50% Capacitance |
|--|---------------------|-----------------|
| PT407, PT410, PT415, PT420 | 10 uF | 5 uF |
| PT007, PT430 | 10 uF | 5 uF |
| PT010, PT020 | 20 uF | 10 uF |
| PTE007, PTE007QT, PTE010, PTE010QT, PTE015, PTE020, PTE407, PTE407QT, PTE410, PTE410QT, PTE415QT, PTE420QT | 20 uF | 10 uF |
| PTE207QT, PTE210QT, PTE215QT, PTE220QT | 20 uF | 10 uF |
| PT030, PT040, PT440, PT450, PT460, PT475 | 40 uF | 20 uF |
| PT050, PT060, PT075, PT4100, PT4150, PT4175 | 80 uF | 40 uF |

For **230V** and **voltage doubling PTE models (PTE0XX and PTE2XX)**, disconnect wires from JL2 and use a multi-meter to measure between JL1 and JL2, then measure between JL2 and JL3B. If either capacitance measured is below the **50% Capacitance** value in **Table 32**, contact Phase Technologies for replacement.




Figure 30 – Measuring PTE0XX Filter Capacitors

For **460V PTE models (PTE4XX)**, disconnect wires from JL2. You may need to remove the baffle covering the heatsink to access JL2. Next, use a multi-meter to measure between L1 and L2, then measure between L2 and JL3B. If either capacitance measured is below the **50% Capacitance** value in **Table 32**, contact Phase Technologies for replacement. Be sure to reconnect wires to JL2 before powering unit on again.




Figure 31 – Measuring PTE4XX Filter Capacitors

Fuses

There are several replaceable fuses in the converter. Each fuse is assigned a designator, indicated by its label. Contact the Phase Technologies Service Department for replacement fuses.

Table 33 – Fuse Information

| Fuse Designator | Locations | 250 V Fuse Rating |
|-----------------|----------------|-------------------|
| F1 | Inverter Board | 3 A Fast Blow |
| F3 | Inverter Board | 3 A Fast Blow |




Figure 32 – PT Small Frame Fuse Location




Figure 33 – PT Medium Frame Fuse Location

Small Frame Models:

PT407, PT410, PT415,
PT420

Medium Frame Models:

PT007, PT010, PT020,
PT430

Large Frame Models:

PT030, PT040, PT050,
PT060, PT075, PT440,
PT450, PT460, PT475,
PT4100, PT4150, PT4175





Figure 34 – PT Large Frame Fuse Locations

Some PTE models may require the heat sink baffle to be removed before accessing fuses. To do this, remove the screws fastening the baffle to the side of the heatsink.


The heat sink baffle is necessary for proper cooling and must be replaced before resuming operation. If not properly replaced, warranty may be voided.





**Figure 35 – PTE Frame 2 Fuse Location
(Heat Sink Baffle Must Be Removed)**

MOTOR STARTING/OVERLOAD CAPABILITIES


All Phase Perfect digital phase convertors are rated to across the line start motors up to the nameplate horsepower rating of the convertor except for 50 HP models and larger. Motor starting capability is approximately equivalent to an across the line starter using a Class 10 thermal overload. This capability is accomplished using a Class 4 thermal overload characteristic with a proprietary algorithm that limits inrush current on the manufactured leg during startup to prevent nuisance tripping. During startup, voltage is folded back when current exceeds 400% of Full Load Amps (FLA) of the converter. Below 400% of FLA, a Class 4 thermal overload curve and thermal measurements, on the IGBTs, control overload tripping.






*PT050, PT060, and PT075 should not be used to cross-the-line-start motor loads.


Overcurrent/Motor Starting Sourcing Limit



Overcurrent/Motor Starting Sourcing Limit



Overcurrent/Motor Starting Sourcing Limit



*Phase converters 50 HP and larger should not be used to cross-the-line start motor loads.

DIMENSIONAL DRAWINGS




Figure 36 – PT Small Frame Dimensions




Figure 37 – PT Medium Frame Dimensions




Figure 38 – PT Large Frame Dimensions




Figure 39 – PTE Small Frame Dimensions




Figure 40 – PTE Medium Frame Dimensions




Figure 41 – PTE Large Frame Dimensions




Figure 42 – PTS003 and PTS005 Dimensions





Figure 43 – PTS007 Dimensions



NOTES



LIMITED WARRANTY

This Limited Warranty applies to the following
Phase Technologies' product lines:

Phase Perfect® Digital Phase Converters One Year Warranty

Phase Perfect Digital Phase Converters are warranted against defects in material and workmanship. This warranty covers both parts and labor from the date of purchase from Phase Technologies. Phase Technologies will repair or replace (at our option), at no charge, any part(s) found to be faulty during the warranty period specified. The warranty repairs must be performed by/at a Phase Technologies Authorized Service Center or at Phase Technologies LLC, Rapid City, SD.

Obligations of Customer

1. The original Bill of Sale must be presented to obtain "in-warranty" service. Transportation to Phase Technologies or an Authorized Service Center is the responsibility of the purchaser. Return transportation is provided by Phase Technologies.
2. Installations must comply with all national and local electrical codes.

Exclusions of the Warranty

This warranty does not cover any of the following: accident, misuse, fire, flood, and other acts of God. Nor does this warranty cover any contingencies beyond the control of Phase Technologies, LLC, including: water damage, incorrect line voltage, improper installation, missing or altered serial numbers, and service performed by an unauthorized facility.

Phase Technologies' liability for any damages caused in association with the use of Phase Technologies' equipment shall be limited to the repair or replacement only of the Phase Technologies' equipment. No person, agent, distributor, dealer, or company is authorized to modify, alter, or change the design of this merchandise without express written approval of Phase Technologies, LLC.

Installations must comply with all national and local electrical code requirements.



222 Disk Drive, Rapid City, SD 57701

866-250-7934 - Toll-Free 605-343-7934 - Main

www.phasetechnologies.com
